



Why is too much background electrolyte BGE a bad thing in CE - FAQ

Too much background electrolyte BGE can cause erratic electroosmotic flow EOF due to an increase in the Joule Heating that may develop due to the higher current.

Printed from the Chrom Resource Center

Copyright 2025, All Rights Apply

MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451

Tel: (732) 380-8900

Fax: (910) 769-9435

Email: customers@mtc-usa.com

Website: www.mtc-usa.com