

How do I minimize bacterial growth in buffers for CE - FAQ

You can keep them in a cold room and you can add a little sodium azide.

Printed from the Chrom Resource Center
Copyright 2025, All Rights Apply
MicroSolv Technology Corporation

9158 Industrial Blvd. NE, Leland, NC 28451

Tel: (732) 380-8900 Fax: (910) 769-9435 Email: customers@mtc-usa.com

Website: www.mtc-usa.com