

## Removing polyimide from capillaries without using heat - How To

To remove polyimide outer coating from capillaries such as Simplus™ brand or Zero Flow™ or Controlled Flow™ capillaries for CE without using heat, it is best to use **fuming** sulfuric acid at 100°C.

You may want to heat the acid on a hot plate in a small shallow plate, using a fume hood and all the safety equipment needed. Then dip the capillary into the hot liquid. After a brief amount of time in the liquid, the polyimide should be able to be wiped away with a clean, soft cloth. Be careful not to apply too much pressure to the capillary. Remember that the detection window is fragile and can break easily.

Best practices in this case may call for practicing with capillary parts before you attempt on a coated capillary.

Click [HERE](#) for ordering information and pictures of CE Capillaries.

Printed from the Chrom Resource Center

Copyright 2025, All Rights Apply

**MicroSolv Technology Corporation**

9158 Industrial Blvd. NE, Leland, NC 28451

Tel: (732) 380-8900

Fax: (910) 769-9435

Email: [customers@mtc-usa.com](mailto:customers@mtc-usa.com)

Website: [www.mtc-usa.com](http://www.mtc-usa.com)